


INSTALLATION SEQUENCE

1. ADHERE PERIMETER ISOLATION BOARD (MODEL SRP) TO WALLS, COLUMNS, PIPES, ETC.
2. ROLL OUT RIM ISOLATION SYSTEM. SPACING BETWEEN PERIMETER AND FIRST ROW OF PADS SHALL NOT EXCEED 4"
3. INSTALL 'HIGH LOAD' PADS WHERE SHOWN ON DRAWINGS. TO INSTALL, CUT AWAY LOW DENSITY FIBER GLASS AND INSTALL KIP PAD "TOP" SIDE UP. CONSTRUCTION ADHESIVE ON THE BOTTOM WILL HOLD THE PAD IN PLACE.
4. LAY FIRST LAYER OF PLYWOOD STAGGERING JOINTS, BUTTING LIGHTLY TO MODEL SRP
5. CAULK CONSTRUCTION ADHESIVE ONTO BOTTOM OF THE SECOND LAYER OF PLYWOOD
6. LAY SECOND LAYER OF PLYWOOD 90 DEGREES TO FIRST LAYER, STAGGERING AND OVERLAPPING ALL JOINTS BY 24".
7. OPTIONAL: MAINTAIN A GAP BETWEEN PLYWOOD SHEETS AS REQUIRED BY FINISH FLOORING MANUFACTURER
8. SCREW AND GLUE PLYWOOD LAYERS TOGETHER WITH 1-1/4" #10 SCREWS ON 8" CENTERS BOTH DIRECTIONS.
9. INSTALL FINISHED FLOOR AS PER MANUFACTURER'S RECOMMENDATIONS.



TITLE ISOLATED WOOD FLOOR
INSTALLATION

LAST DATE
REVISED
6/20/07

DRAWN BY
MVG

DRAWING NO.
FF-9609-2

ROLL-OUT ISOLATION MATERIAL / FIBERGLASS ISOLATOR
MODEL RIM / KIP
INSTALLATION GUIDELINES FOR WOOD FLOOR

Preparation

- Subfloor shall be clean, flat, and level.
- Ensure a strong, rigid subfloor with deflection not exceeding 1/360 of the span, including live and dead loads.
- Max. variation in the slab height shall be ¼-inch in 10-feet and 1/8-inch in 4 feet from the required plane.
- Slope of subfloor shall not exceed ¼-inch per foot unless specifically addressed in the submittal documents.
- Fill cracks and remove residue.
- If a waterproof membrane is installed on structural floor, it shall be load bearing.
- Concrete subfloor shall be troweled smooth, free from spills/voids, and be clean and dry.
- Wood subfloors shall be free of weak spots, squeaks, protruding nails, screws, staples, and be clean and dry.

Kinetics Noise Control Model SRP Perimeter Isolation

1. Cut Kinetics Model SRP isolation material to a width equal to ¼-inch less than planned floor system height.
2. Apply spray adhesive (such as Camie 363 High Strength Fast Tack Spray Adhesive), following manufactures directions, to one side of Kinetics Model SRP perimeter isolation material (alternatively double sided tape may be used).
3. Firmly adhere it to any wall or vertical position (including door frames) surrounding the perimeter of the Model RIM/KIP installation area.
4. Adhere Kinetics Model SRP to any protrusions through the floor system including floor drains, columns, pipes, conduit, etc following steps 1-3.

Note: Never attach the perimeter isolation board with nails, screws, or staples.

Option A) Model KIP pad installation

- 5A. Locate isolation pads per submittal drawing. Pad spacing will vary depending on load requirements, Maximum spacing 16" o.c. It is recommended to snap chalk lines to align pads. There shall be no more than 4" between the perimeter and the first row of pads.

Note: All isolation pads are of the same density.

- 6A. Apply a dab of construction adhesive to bottom of pad before setting on the floor.

Note: Top of pad is clearly stamped and must be oriented with "Top" side up to perform properly. No adhesive required on top of isolator pad

Option B) Model RIM installation

- 5B Roll out the Model RIM material onto the subfloor so that there is no more than 4" from the perimeter of the installation area and first row of pads.
- 6B Maintain equal spacing between pads from one roll of material to the next as there is between pads on the same roll. (i.e 12", 16", 24"....)
- 7B If needed, install a row of pads to maintain maximum spacing of pads from wall.
- Cut away low density fiber glass
 - Install pads as described in option A.
- 8B If indicated on submittal drawings, install "High Load" pads.
- Locate "High Load" pad location
 - Cut away low density fiber glass
 - Install pads as described in option A.

Floating Wood Floor Installation

- 9 Lay the first layer of at least ½" thick C grade, sheathing, EXP-1, fir, 4 ply. plywood on top of pads, butting up to but not compressing against the perimeter isolation board. Stagger joints between rows by 4 ft.
- 10 Prior to installing the second layer of plywood, apply approximately 10 oz of construction adhesive onto bottom side of plywood by means of a caulking gun. Alternatively, trowel construction adhesive onto the first layer of plywood with a 3/16" wide x ¼" deep x ½" C-C V-notch trowel.
- 11 Lay second layer of plywood on top of first layer of plywood at a 90° relation, staggering and overlapping joints a minimum of 24 inches top to bottom.

Note: Spacing of the top layer of plywood, edge to edge, should be determined by the finish flooring manufacturer. Example: Hardwood floor companies often recommend a 1/8" space between plywood sheets (top layer).

- 12 Using a 1 ¼" #10 screw, screw 8" o.c. in every direction. Start your row of screws 3" away from the edge of the second layer of plywood. If using plywood thicker than ½", increase screw length appropriately, while insuring that screws will not penetrate bottom layer by more than ¼".
- 13 Install finish flooring per recommendations of the flooring manufacturer.

Disclaimer

These suggested installation guidelines represent generally accepted procedures for successful installation of Kinetics Noise Control Model RIM Roll-out Isolation Material / KIP Fiberglass isolators for floating wood floor isolation. These suggestions may be followed, modified, or rejected by the owner, engineer, contractor, and/or their respective representative(s) since they, not Kinetics Noise Control, are responsible for planning and executing procedures appropriate to a specific application. Kinetics Noise Control reserves the right to alter these suggestions and encourages contact with the factory or its representatives to review any possible modification to these suggested guidelines prior to commencing installation